

GigBAR MOVE + ILS

FIRMWARE UPDATE PROCEDURES

These firmware updates provide bug fixes and improvements to your Gigbar Move + ILS experience. Please review all information below prior to updating your fixture.

<u>US Software Version</u>	<u>EU Software Version</u>	<u>Description</u>
1.17	1.18	Improved sound sensitivity for moving heads
1.21	1.22	Added "sound loss" mode
n/a	1.23	Fixed a master/slave bug
2	2	Added "par color" mode which limits the colors to tri, quad or hex
2.01	2.01	Fix bug on initial start up
2.02	2.02	Added pan/tilt ranges for auto/sound programs
2.03	2.03	Added manual "XY speed" control in sound mode
2.04	2.04	Improved XY motor slipping in sound mode

Special Notes:

1. Do not use a thumb drive greater than 32GB.
2. The thumb drive must be formatted to FAT32.
3. Do not store more than a single firmware file on the thumb drive at any time.
4. The downloaded firmware file must be the only file on the thumb drive and placed in the root directory (no folders).

Firmware Update Instructions:

1. Download the ZIP file onto your computer and extract the folder.
2. Transfer the contents from the ZIP file onto a USB thumb drive.
3. While the GigBAR Move + ILS is powered off, hold down the menu button and apply power. This will set the fixture into "firmware update mode".
4. Insert the USB thumb drive into the USB port on the rear of the unit and the GigBAR Move + ILS will automatically find the firmware and apply it.
5. The fixture will reset itself automatically and display the new firmware version during startup.
6. The USB thumb drive can be removed after the fixture restarts.

