

FIRMWARE UPDATE PROCEDURES

These firmware updates provide bug fixes and improvements to your Gigbar Move ILS experience. Please review all information below prior to updating your fixture.

<u>US Version</u>	<u>EU Version</u>	<u>Description</u>
1.09		Initial release
1.10		Fixed a bug with hard wire DMX signal

Special Notes:

1. Do not use a thumb drive greater than 32GB.
2. The thumb drive must be formatted to FAT32.
3. Do not store more than a single firmware file on the thumb drive at any time.
4. The downloaded firmware file must be the only file on the thumb drive and placed in the root directory (no folders).

Firmware Update Instructions:

1. Download the ZIP file onto your computer and extract the folder.
2. Transfer the contents from the ZIP file onto a USB thumb drive.
3. Hold down the menu button then power on the fixture to put it into upload mode.
4. Insert the USB thumb drive into the USB port on the rear of your unit, the Gigbar Move ILS will automatically find the firmware and apply it.
5. The fixture will reset itself automatically and display the new firmware version during startup.
6. The USB thumb drive can be removed after the fixture restarts.